## AMERICAN CUBE MOLD, INC.

## **TESTING EQUIPMENT**

(330) 558-0044

(330) 558-0055 FAX

\*CEMENT \*MORTAR \*GROUT TESTING \*EPOXIES

## ACM-1K

## **DIRECTIONS**

- 1. For ease of stripping, lightly oil or spray releasing agent onto plastic form.
- 2. Place a layer of mortar about 1 inch in all of the cube compartments; tamp the mortar (with tamper provided) 32 times in rounds, each round to be at right angles to the other.
- 3. Fill the compartments to overflowing and tamp same as specified for the first layer.
- 4. Smooth the mortar to a plane surface flush with the top of the mold.
- 5. Cover, Cure, store as directed by mortar manufacturer's instructions, or as specified in ASTM.
- 6. When cubes are ready for removal, remove bands and disassemble mold to retrieve test samples.
- 7. Clean & reassemble mold for future use.