

NUK LOCK SECURITY SYSTEM

1. Lay cable system flat with yellow markers on bottom and green loops on sides.
2. Place nuk case on top of yellow markers.
3. Take blue long rein (not blue loop) through top handle and through blue loop.
4. Take blue rein through either side handle and through green loop.
5. Pull tightly so cable is snug.
6. Lock to truck making sure cable is tight.
7. Take long red rein and pull through top handle and through red loop.
8. Attach through other side handle and through green loop.
9. Pull tightly so cable is snug.
10. Lock to truck making sure cable is tight.

PLEASE NOTE: Cable must be tight around case to ensure no access to equipment.